



For a 1k potentiometer, use 2x 220R to shrink the values to 0x06..0xFA. For an amplified input like distance sensors, use 2x0R to power with GND and +5V.

The MIT License

Kastanie Eins

Sheet: /

File: analog.sch

Title: Exponent Analog

Size: A4 Date: May 2021

KiCad E.D.A. eeschema (5.1.9) - 1

Rev: 0.3

Id: 1/1